



Position	Code	description
02	103503	Pumice stone
03	4113B01	Pumice stone tray
04	218A002207	KNOB
05	073060	Control lamp cover (Orange)
06	053079	Knob rubber
08	333B014SDL	WORK TOP
09	073043	Control lamp L 200
10	053055	Switch gasket
12	050019004	Energy regulator
13	4113B02	Casing
14	094347	Front fixing bracket (to fix the appliance to the cabinet)
15	001069	Stainless steel screw
16	051046	Terminal block
18	053065	Seal
20	035096	Spring
21	103534	Ball
22	071057	Bolt
23	053081	Gasket
24	4933B001	Tiltable electric element group
25	ES000	*NOT AVAILABLE
26	003056	O ring
27	062085004	Tiltable electric element