




SERVICE

LA SUPERCALOR "INT" HG 66



| Position | Code       | description              |
|----------|------------|--------------------------|
|          | 566724     | POLYSTYRENE UPPER        |
|          | 566725     | POLYSTYRENE LOWER        |
|          | 573108     | INSTRUCTION BOOK         |
| 001      | 6912610018 | TRAY                     |
| 002      | 535310     | HANDLE                   |
| 003      | VI000      | SEE TECNICAL INFORMATION |
| 004      | 552211     | FOOT                     |
| 005      | 591977     | SLIDER LEFT              |
| 006      | 591976     | SLIDER RIGHT             |
| 007      | 5512600008 | HEATING Element          |
| 008      | 511855     | MICROSWITCH              |
| 009      | 535035     | LEVER                    |
| 010      | 535034     | HOOK                     |
| 011      | 606950     | SPRING                   |
| 012      | 535031     | CONTROL PANEL            |
| 013      | 5112610211 | SWITCH                   |
| 014      | 591978     | CONTROL PANEL            |
| 015      | 5312610421 | HANDLE                   |
| 016      | 611852     | GRID                     |