



Position	Code	description
01	LU1000	COVER
06	LU1001	GRID
07	LU1002	CLIP
08	LU1003	CLIP
09	LU1004	TUBE
10	LU1005	HANDLE
11	LU1006	UPPER BODY
13	LU1007	HEATING Element
15	LU1009	KNOB
16	LU1010	LENS
18	LU1011	PANEL
21	LU1012	CONNECTOR
22	LU1013	THERMOSTAT
23	LU1014	CONTROL PANEL
25	LU1015	SUPPORT
30	LU1016	MICROSWITCH
31	LU1017	EXTENSION
33	LU1018	COVER
34	LU1019	LOWER BODY
36	LU1020	TRAY
38	LU1021	SUPPORT
40	LU1022	SUPPORT
41	LU1023	TRAY
43	LU1024	SUPPORT
44	LU1025	TRAY
46	LU1026	TUBE
47	LU1027	TUBE
48	LU1028	TUBE
50	LU1029	RUBBER PAD
51	LU1030	CASTOR
55	LU1031	TUBE
59	LU1032	PUSH BUTTON
61	LU1033	POWER SUPPLY CORD
62	LU1034	NUT