



Position	Code	description
01	5325121700	COVER
02	5325121400	GRID
03	5325115200	GLASS
04	5325112900	HINGE LEFT
05	6125102600	SPRING
06	6125101900	PIN
07	6125102500	SPRING
08	5325113000	HINGE RIGHT
09	6925101700	INNER COVER
10	7325114300	COVER
11	7325114200	PAN
12	7025100700	BASKET
13	5525100000	HANDLE
14	ES000	*NOT AVAILABLE
15	511816	FUSE
16	5325113900	SPACER
17	5325114000	SPACER
18	5325104700	SPACER
19	5325121200	CASING
20	6125102300	SPRING
22	5325113700	PUSH BUTTON
23	5525102800	PEDESTAL
24	532233	RUBBER PAD
25	5925111100	CONTROL PANEL
26	513080	LAMP
27	5311811071	RED LENS
29	5325106400	BUSH