



| Position | Code       | description       |
|----------|------------|-------------------|
| 01       | 5325112900 | HINGE LEFT        |
| 02       | 6125102600 | SPRING            |
| 03       | 6125101900 | PIN               |
| 04       | 6125102500 | SPRING            |
| 05       | 5325113000 | HINGE RIGHT       |
| 06       | 5325113600 | GRID              |
| 07       | 5325117500 | COVER             |
| 08       | 6925102900 | INNER COVER       |
| 09       | 5325143300 | GASKET            |
| 10       | 7025105700 | BASKET            |
| 11       | 7325117900 | COVER             |
| 12       | 7312577499 | BASKET AND HANDLE |
| 13       | ES000      | *NOT AVAILABLE    |
| 14       | 7325113900 | PAN               |
| 15       | 512113     | MICROSWITCH       |
| 16       | 5225101300 | THERMOSTAT        |
| 17       | 5325120200 | GEAR              |
| 18       | 5325120100 | LEVER             |
| 19       | 9824800015 | CLIP CLAMP        |
| 20       | 5512500089 | TUBE              |
| 21       | 5325120600 | STOPPER           |
| 22       | 536330     | BRUSH             |
| 23       | 5325114000 | SPACER            |
| 24       | 5325113900 | SPACER            |
| 25       | 5325104700 | SPACER            |
| 26       | 5325120500 | CASING            |
| 27       | 5925112700 | CONTROL PANEL     |
| 28       | 6125103400 | SPRING            |
| 29       | 5325127300 | PUSH BUTTON       |
| 30       | 513080     | LAMP              |
| 31       | 5311811071 | RED LENS          |
| 32       | 5325120000 | SLIDER            |
| 33       | 6125102900 | PIN               |
| 34       | 5925112500 | DOOR              |
| 35       | 511816     | FUSE              |
| 36       | 5525102400 | PEDESTAL          |
| 37       | 532233     | RUBBER PAD        |

|    |            |             |
|----|------------|-------------|
| 38 | 5325106400 | BUSH        |
| 39 | 5225100200 | TIMER       |
| 40 | 5325118400 | SUPPORT     |
| 41 | 5325118500 | PUSH BUTTON |