



Position	Code	description
001	5325112900	HINGE LEFT
002	6125100300	SPRING
003	6125100400	PIN
004	6125103000	SPRING
005	5325113000	HINGE RIGHT
006	5325105200	GRID
007	5325105100	COVER
009	ES000	*NOT AVAILABLE
010	5512500049	GUARNIZIONE
011	7312576139	COVER
012	5325104800	SPACER
013	5325104900	SPACER
014	5325104700	SPACER
016	5525100200	HOOK
017	6125100800	SPRING
018	5325127400	CASING
019	536330	BRUSH
020	7325137200	PAN
022	9824800015	CLIP CLAMP
023	5512500089	TUBE
024	5325120600	STOPPER
025	511816	FUSE
026	6225101200	STOP
027	5525108300	PEDESTAL
029	611912	SPRING
030	5325106400	BUSH
031	5325147400	BOTTOM
032	5512500019	BASKET ASSEMBLY
036	5512500139	HANDLE
037	5225100700	THERMOSTAT 145
039	5925109100	CONTROL PANEL
040	5325104600	PUSH BUTTON
043	5325140400	KNOB
044	9824800014	CLIP CLAMP
045	5325103900	BUSH
046	5325104000	BUSH
047	5325102600	EXTENSION

048	5112510031	SWITCH
049	513080	LAMP
050	5311811071	RED LENS
051	5925106400	DOOR
052	6225101300	FLANGE
053	5325111100	GASKET
054	532524	GASKET
055	622063	PIN
056	532509	CLIP CLAMP
057	9821002346	WASHER
058	9815002086	NUT