



Position	Code	description
01	5325154900	HINGE LEFT
02	6125103700	SPRING
03	6125103600	SPRING
04	5325154800	HINGE RIGHT
06	VN039	SEE NOTE
07	5325143100	COVER
08	5325133800	GLASS
09	6925104200	INNER COVER
10	5325143500	GASKET
11	7325124700	COVER
12	5325144000	SPACER
13	5325143900	SPACER
14	5325104700	SPACER
16	5525106200	HOOK
17	6125104100	SPRING
18	5325143800	CASING
19	536330	BRUSH
20	7325126100	PAN
21	5325133900	BLOCK
22	9824800015	CLIP CLAMP
23	5512500089	TUBE
24	5325120600	STOPPER
25	511875	TCO 216°
27	5525105400	BASE
28	5325139700	DRAWER
29	532233	RUBBER PAD
30	5325146800	BUSH
31	5325135600	COVER
32	7025102100	BASKET
34	5525105800	FILTER
35	ES000	*NOT AVAILABLE
36	7312573089	HANDLE
37	5225101600	THERMOSTAT
38	5325135100	SUPPORT
39	5925116400	CONTROL PANEL
42	5325136300	PUSH BUTTON
43	5325146900	KNOB

44	9824800014	CLIP CLAMP
46	5325143200	BUSH
47	5325136000	EXTENSION
48	5112510031	SWITCH
49	513080	LAMP
50	5311811071	RED LENS
51	5325139500	DOOR
53	5225100200	TIMER
54	5325135700	Front Protection
55	5325135200	PUSH BUTTON
56	5325149600	Rear Protection