



Position	Code	description
1	AT6196000600	COVER ASSY 4600
2	AT6195390100	SPACER 4600
3	AT6196000700	BASKET ASSY 4600
4	AT6196000800	OIL SEAT ASSY 4600
5	AT6195740200	THERMOSTAT 4600
6	AT6196000900	BODY AND BASE ASSY 4600
7	AT6195590200	PIEDINI 4600
8	AT6196001000	LAMP WIRE ASSY
10	AT6196001100	THERMOFUSE AND BRACKET ASSY
11	AT6195311300	FILTER 4600