



Pos	Codice	Italiano	English	Francais	Deutsch	Espanol
001	536125	GRIGLIA	GRID	GRILLE	GITTER	PARRILLA
002	592679	COPERCHIO	COVER	COUVERCLE	DECKEL	TAPA
003	611930	MOLLA	SPRING	RESSORT	FEDER	MUELLE
004	536126	GANCIO	HOOK	CROCHET	HAKEN	GANCHO
006	690421	CONTROCOPERCHIO	INNER COVER	CONTRE COUVERCLE	GEGENDECKEL	DOBLE TAPA
007	611929	MOLLA	SPRING	RESSORT	FEDER	MUELLE
008	611927	PERNO	PIN	PIVOT	STIFT	PERNO
009	737026	COPERCHIO	COVER	COUVERCLE	DECKEL	TAPA
010	536586	GUARNIZIONE	GASKET	JOINT	DICHTUNG	GUARNICION
011	607749	FERMO	STOP	ARRET	SPERRUNG	TOPE
012	5325106200	CHIUSURA	CLOSURE	FERMETURE	VERSCHLUSS	CIERRE
013	536151	CORNICE	FRAME	ENCADREMENT	RAHMEN	MARCO
015	536127	INVOLUCRO	CASING	ENVELOPPE	GEHAEUSE	ENVOLTURA
016	611937	MOLLA	SPRING	RESSORT	FEDER	MUELLE
017	536129	TASTO	PUSH BUTTON	POUSSOIR	TASTE	TECLA
018	611928	PERNO	PIN	PIVOT	STIFT	PERNO
019	592658	PORTA	DOOR	PORTE	TUER	PUERTA
020	592782	TAPPO	STOPPER	BOUCHON	STOEPSSEL	TAPON
021	536335	GEMMA	LENS	LENTILLE	LINSE	PILOTO
022	512818	SPIA	WARNING LIGHT	TEMOIN LUMINEUX	KONTROLLEUCHTE	PILOTO
023	511816	TERMOFUSIBILE	FUSE	FUSIBLE	SCHMELZSICHERUNG	FUSIBLE
024	5125100300	INTERRUTTORE	SWITCH	INTERRUPTEUR	SCHALTER	INTERRUPTOR
025	552419	PIEDISTALLO	PEDESTAL	PIEDESTAL	SOCKEL	PEDESTAL
028	536136	FONDO	BOTTOM	FOND	BODEN	FONDO
029	534749	TAPPO	STOPPER	BOUCHON	STOEPSSEL	TAPON
030	536159	TUBO	TUBE	TUBE	ROHR	TUBO
031	592657	CURSORE	SLIDER	CURSEUR	SCHIEBER	CURSOR
032	536256	INGRANAGGIO	GEAR	ENGRENAGE	GETRIEBE	ENGRANAJE
033	521519	TERMOSTATO	THERMOSTAT	THERMOSTAT	THERMOSTAT	TERMOSTATO
034	9824800015	FASCETTA	CLIP CLAMP	COLLIER	SHELLE	ABRAZADERA
035	737012	IMPUGNATURA	HANDLE	POIGNEE	GRIFF	EMPUÑADURA
036	708970	CESTELLO	BASKET	PANIER	KORB	CESTO
037	6025102000	SQUADRETTA	BRACKET	EQUERRE	WINKEL	ESCUADRA
039	7325107300	VASCA	PAN	CUVE	BEHAELTER	CUBA
040	536152	CORNICE	FRAME	ENCADREMENT	RAHMEN	MARCO
041	536330	SPAZZOLINO	BRUSH	BROSSE	BUERSTCHEN	CEPILLO
042	532233	GOMMINO	RUBBER PAD	PARE CHOCS	PUFFER	GUARNICION