





Ersatzteilkatalog**Spare parts list****PALUX Cook´n Roll****Auftisch- und Einbaugeräte****Front-Cooking-Center**

Deep fat fryer, Chip scuttle



Pos.	Description	Article
1	basket for deep-fat fryer	687723
2	container	689122
3	lamp green 250V	689017
4	lamp yellow 250V	689025
5	toggle	393800
6	Bedienfolie Friteuse	
7	outlet tap	688916
8	container	689645
9	lamp green 250V	689017
10	Bedienfolie Frittenwanne	
	adjustable foot	689068
	- Friteuse -	
	limit switch	689289
	heating element 230V 5800W	689297
	safety thermostat	689300
	thermostat	689319
	relay	689327
	support f. basket	689130
	handle	689149
	filter system	687731
	- Frittenwanne -	
	heating element 230V 175W	689653
	heating element	689661
	DrehSchalter Frittenwanne	689718