



| Position | Code | description |
|----------|------------|--------------------|
| 01 | 7012610021 | PLATE |
| 02 | 5112610221 | HEATING Element |
| 03 | 5312610081 | TRAY |
| 04 | 5312610331 | COVER SX |
| 06 | 5312610291 | SIDE LEFT |
| 08 | 5312610311 | FOOT LEFT |
| 09 | 5312610251 | RUBBER PAD |
| 10 | 7312610198 | TRAY |
| 12 | 5312610301 | SIDE RIGHT |
| 14 | 5312610151 | THERMOSTAT GEAR |
| 15 | 5312610141 | KNOB GEAR |
| 16 | 5212610001 | THERMOSTAT |
| 17 | 6112610001 | GRID |
| 18 | 5112610151 | LAMP |
| 19 | 5312610111 | LENS |
| 20 | 5912610031 | COVER DX |
| 21 | 5012611181 | POWER SUPPLY CORD |
| 22 | 5312610381 | CLOSURE RIGHT |
| 23 | 5218101100 | TCO 133° |
| 24 | 5112510031 | SWITCH |
| 25 | 5912610011 | KNOB |
| 26 | 5112610181 | SPRING MICROSWITCH |
| 28 | 6112610011 | SPRING |
| 29 | 5312610271 | LEVER |
| 30 | 5312610341 | FOOT RIGHT |