



Position	Code	description
01	TK1180	LABEL
02	TK1181	FRONT PIECE
03	TK1182	COVER
04	TK1183	LEVER DX
05	TK1184	LEVER SX
06	TK1185	HANDLE
07	TK1186	LEVER
08	TK1187	HOOK
09	TK1188	SPRING
11	TK1190	INSULATOR
13	TK1270	PLATE Upper
14	TK1271	PLATE LOWER
15	TK1194	INSULATOR
16	TK1195	CONTAINER
17	TK1196	COVER
18	TK1197	COVER
19	TK1226	THERMOSTAT
20	TK1199	PROTECTION
21	TK1200	COVER
22	TK1201	WARNING LIGHT
23	TK1202	GLASS
24	TK1203	PANEL
25	TK1204	SUPPORT BASE
26	TK1205	PROTECTION
27	TK1206	INDICATOR
28	TK1207	KNOB
30	TK1209	SUPPORT BASE
31	TK1210	COVER
32	TK1232	POWER SUPPLY CORD
33	TK1228	WIRING
34	TK1213	TERMINAL
47	TK1214	CLIP
50	TK1215	FOOT
51	TK1229	FUSE