





Position of item	Code	Nr. of pieces	Description
1	30168500	1	ORANGE LIGHT 230V Ø10 mm T150°
2	34068300	1	THERMOSTAT FOR PLATE WARMER
3	30654300	1	KNOB FOR TOASTER
4	30684100	4	FOOT FOR STAND-ALONE EQUIPMENT
5	34031900	1	400W-230V HEATING ELEMENT
6	34643900	2	GRILL SPT 30-60
7	32583800	1	DOOR MAGNETIC CLOSING
8	34186700	1	CABLE GUIDE